



## GUARD RAIL SECTION ERECTION INSTRUCTIONS WIDE SPAN SCAFFOLD

**LIGHT  
DUTY**

25 LBS./SQ. FT. (500 LBS. MAXIMUM) 1 PERSON PER ALDEK®  
PLATFORM BOARD. 1000 LBS. MAXIMUM PER SCAFFOLD.

MINIMUM BRACE REQUIREMENTS FOR THIS SECTION 1 DIAGONAL, 4 HORIZONTALS

**READ AND UNDERSTAND ALL INSTRUCTIONS  
ON THIS SCAFFOLD**


**WARNING:**

FAILURE TO COMPLY WITH THESE INSTRUCTIONS MAY RESULT  
IN SERIOUS INJURY.

### 2 SET-UP GUARDRAIL SECTION

- A** Insert stacking pins of guardrail section frames into sockets on top of vertical posts of frames of section below.

**A**  
GUARDRAIL  
SECTION  
ENDFRAMES



- B** Position interlock pin through aligned holes as shown (see Figure a)

Be certain that pin securely engages both the upper endframe stacking pin and the lower endframe vertical post. After the pin is engaged, the spring clip should rest flush against the vertical post as shown (see Figure b)

**B**

Figure a




Figure b




Pin Securely  
Engaged

- C** Attach horizontal braces to frame rungs on both sides of guardrail section to act as guardrails and midrails.


**C**

GUARD  
RAILS  
MID  
RAILS



- D** Move platform to highest level below guardrail section.

**D**



# CAUTION

**READ INSTRUCTION  
LABEL ON UNDERSIDE  
OF PLATFORM**

**OSHA** **REQUIRES**  
**TOEBOARDS, HANDRAIL**  
**AND SCREENING**

**CHECK OSHA & STATE CODES  
FOR DETAILS OF REQUIREMENT**